

## MODEL: K3-2 Card Access

**Installer Code: \*888888#**

### 1) Install Cards (1000 user)

**\*888888# → Press 1 → XXX # → Flash First Card**

**(Second Card) → XXX # → Flash Second Card**

**(Third Card) → XXX # → Flash Third Card → Follow the same step for fourth and more card. END.....\*(Exit)**

**NOTE: XXX is CARD LAST 3 Digit.**

### 2) Operation Mode

a) **\*888888# → 30 #\* (Card Only)**

b) **\*888888# → 31 #\* (Card and PIN )**

c) **\*888888# → 32 #\* (Card or PIN) ---Default**

### 3) Add/ Changing User PIN

**NOTE:Access without installer Code→**

**\*→Flash User Card →1234# →(4 Digit NEW PIN) # →(repeat 4 Digit NEW PIN) # → “\*”**

NOTE: a)PIN number can be any 4 Digit,except”1234”.

b)after program the PIN ,pls MARK the CARD for next times when changing the existing PIN.

**: Release Door: Press→ User PIN #**

### 4) Delete Card

a) **\*888888# → 2→Card number #\* (delete individual card by using last 3digits of card)**

b) **\*888888# → 2→Flash Card #\* (delete by using card)- more cards repeat)**

c) **\*888888# → 2→0000 #\* (delete all data)**

### 5) Door Release Time (default 5sec)

**\*888888# → 4 →XX(00-99) #\***

### 6) Changing Installer Code

**\*888888# → 0 → XXXX # XXXX #\***

(xxxx is NEW Installer Code)

### 7) Setting Door Open Detection

a) **\*888888# → 60 #\* (disable) ---default**

b) **\*888888# → 61 #\* (enable)**

### 8) Resetting To Factory Default Setting

**OFF Power→press the “K2 RESET”  
and hold it →ON Power, keep hold  
and hear 3 Beeps sound.**

