

MODEL: K2 Card Access

Installer Code: *9999#

1) Install Cards (1000 user)

Installer Code→

Press 1→Flash First Card →XXX →# →1 →Flash Second Card →XXX →# →1 →Flash Third Card→XXX→#.....*

2) Operation Mode

Installer Code→

- a) **300 #* (Card Only) --- default**
- b) **301 #* (Card and PIN)**
- c) **302 #* (Card or PIN)**

3) Add/ Changing User PIN

NOTE:Access without installer Code→

→Flash User Card →1234# →XXXX# XXXX #→

NOTE:password number can be any 4 Digit,except"1234" : Release Door: Press→ User PIN #

4) Delete Card

Installer code

- a) **2→Card number #* (delete individual card by using last 3digits of card)**
- b) **2→Flash Card #* (delete by using card)- more cards repeat)**
- c) **2→0000 #* (delete all data)**

5) Door Release Time (default 3sec)

Installer code→ 4 →XX #* (00-99sec)

6) Changing Installer Code

Installer code→ 0 → XXXX # XXXX #*

7) Setting Door Open Detection

Installer Code→

- a) **6 00 #* (disable) ---default**
- b) **6 01 #* (enable)**

8) Resetting To Factory Default Setting

**OFF Power→press the "k2 REST PIN" hold it
→ON Power, keep hold around 5sec until hear
Beeps.**

