

MODEL: kaise RF-198

Installer Code: *8888#

1) Install Cards

Installer Code→

Press 2→0XX→Flash First Card→#→2→0XX→Flash Second Card→#→2→0XX→Flash Third Card→#.....*

Note: Must keyin 3 digit but first digit is "0", second & third digit is last 2 numbers of card.

2) Operation Mode

Installer Code→

- a) **100 #* (Card Only) --- default**
- b) **101 #* (Card and PIN)**
- c) **102 #* (Card or PIN)**

3) Add/ Changing User PIN

Installer Code→

Press 8→XXXX# XXXX #→*

Release Door: Press→ User PIN #

4) Delete Card

Installer code→

- a) **3→Card number #* (delete individual card by using last 3digits of card)**
- b) **3→Flash Card #* (delete by using card)- more cards repeat)**
- c) **3→0000 #* (delete all data)**

5) Door Release Time (default 3sec)

Installer code→ 4 →XX #*
(00-99sec)

6) Changing Installer Code

Installer code→ 0 → XXXX # XXXX #*

7) Setting Door Open Detection

Installer Code→

- a) **5 00 #* (disable) ---default**
- b) **5 01 #* (enable)**

8) Resetting To Factory Default Setting

Installer Code→

**Press 9 86→#→Buzzer "Beeping 3 times"
→wait 10 second Buzzer 'Beeping 6 times'**

9) Resetting To Factory Default Setting

Installer Code→

Short the "J2 RST" jumper →ON Power and OFF Power.

