

USE KEYPAD COMMAND SUMMARY TO CHANGE PASSWORD

PRESS: -

1111 SET # 1 1234 #

1234 SET # 2 XXXX (USER2 PASSWORD) #

1234 SET # 3 XXXX (USER3 PASSWORD) #

Note : 1111 is default master password

Maximum up to 9 user

Example : 1234 is new master password

KEYPAD COMMAND SUMMARY FUNCTION

CHECK ZONE OPEN : 7 #

PANIC : 0 #

SILENT PANIC : 9 #

ALARM EVENT : 6 #

REVIEW TIME & DATE : 8 #

SMART DIALER SUMMARY (USER CALL IN)

XXXX (Password) * 01 # Away Mode

XXXX (Password) * 03 # Disarm

XXXX (Password) * 07 # Panic

SMART DIALER SUMMARY (Alarm Call Out)

After the siren stop : Press 05 # (Cancel the siren but still in arming mode)

USER GSM DIALER SUMMARY

Arm/Disarm (Default 1111)	Master Password 01 Send (Arm) Master Password 02 Send (Disarm) Master Password 07 Send (Panic Alarm)
Add/Modify Password	Master Password 20 n (New Password) Send Value Of n 1 = Master Password 2-9 = User Password

INSTALLER GSM DIALER SUMMARY

Change Reporting Phone Number	Installer Password 40 X (Max 14 digits Phone Number) Send Value Of X =(1-2 CMS)(3-6 Voice Dailer)(7-9 SMS)(10 CMS SMS)
Modify Installer Password	Installer Password 20 n (New Installer Password) Send Value Of n=0 (Default Installer Password 0000)
CMS Account ID	Installer Password 44 XXXX Send Value Of X = CMS ID (MAX 4 Digits)
Communication Protocol	Installer Password 45 X Send Value Of X = (1 . Fronti 2. Contact ID)(Default 2)